DVR EXPRESS®

CORE 2 MAX

SERVER OPTION Quick Start Card

Packing List

Standard Components (included with each DVR Express® Core 2 MAX SERVER)

DVR Express®
Core 2 MAX SERVER

AC Power Cord
(N. America 3-prong)

Replacement:
P/N ACPWRCORDNA

LTC Input Cable



Replacement:
P/N CABC2MAXLTC

Software and
Documentation CD

Auxiliary I/O Cable Kit
(1) DB26 Male Connector
(1) DB26 Backshell Kit

Keys for Rugged
Drive Cartridges (4)

Keys for OS/Export
Drive Cartridges (3)

Optional Accessories

Rack Mounting Shelf

P/N C2MAXSHELF

AC Power Cord
(EU or UK, 3-prong)

P/N ACPWRCRDEU
P/N ACPWRCRDUK

eSATA Cable Anchor Kit
Aluminum bracket secures
eSATA cable to recorder



P/N COREANCHOR

System Connections

The DVR Express® Core 2 MAX SERVER is an integrated digital video recorder and computer system in a single 19" 2U chassis. Local operators can connect a standard USB keyboard, mouse and LCD display. Remote operators can use Remote Desktop or similar solutions for network-based control.

Example Configuration



IO INDUSTRIES

Quick Start Checklist

A version of this Quick Start Checklist can be found in Section 1 of the DVR Express® Core 2 MAX User's Manual, with references to related sections of the manual. The User's Manual can be found on the Software and Documentation CD.

1. Gather Required Components.

a) DVR Express® Core 2 MAX SERVER recorder.
b) Cameras, camera power supplies, video interface cables as needed.

2. Connect Components.

a) Connect cameras to recorder using camera interface cables.
Note: Camera Link cameras are not hot-pluggable! Power off the camera or the recorder before making connections.
b) Connect power to cameras.
c) Connect power to recorder.
d) The recorder immediately turns on when the power supply is connected. To turn off the recorder, press and hold the power button for 2 seconds. It will shut off shortly after. As long as the power supply remains connected, the recorder can be turned back on with a single press of the power button.

3. Launch CoreView from the Windows Start Menu or Desktop Shortcut.

For Start Menu, go to: Programs -> IO Industries -> DVR Express Core x64 -> CoreView

5. Follow the steps in the "New Camera Wizard" to add cameras to CoreView.

6. Click the "Live" button on the DVR Controls to test camera connections

- Verify that images are being received from the attached cameras.
- *For further help, press "F1" to open the CoreVIew User Guide.*

The system is now ready to record video!